

PASSENGER BUTLER MOUNTING ON THE HARLEY ULTRA CLASSIC OR ELECTRA GLIDE

Mount the “female” portion of the hinge to the right side speaker housing. The female part of the hinge is the one that has two countersunk holes. First remove the speaker, then position the hinge piece slightly to the back of and above a spot directly in the center of the side of the speaker housing. Use your judgment here. What you want is for the speaker to reinsert without any inside contact with your mounting bolts, for the ring (once installed) to be level to the ground, with clearance for the mug, and for the ring to aim towards the back of the bike (note: some passengers want the ring to aim to the front, this is fine; really, this is user preference only). Once positioned, drill a 1/4” hole through the side of the speaker housing using one of the two countersunk holes as a guide. Go ahead and put the flat head bolt in and tighten with a washer and lock nut. This is where you can make your final assessment as to the ring being level with the ground. Once your satisfied, drill the second hole, bolt it up and replace the speaker. If you would like to call and discuss the procedure before starting, please feel free to call us at 512-768-3908.

